



T (450) 978-3403

1 (888) 528-8518

F (450) 978-2542

4656 Louis B. Mayer, Laval, QC H7P 6E4

www.durodesign.com

REFINISHING A DURODESIGN OIL-FINISHED WIDE-PLANK PINE FLOOR

REPAIRING YOUR DURODESIGN UV OIL FINISH IS EASY

But first... You must read and understand these instructions completely before refurbishing a DuroDesign knotty-pine wide-plank floor. In the event these instructions leave unanswered questions or if you would like additional information, please contact DuroDesign Customer Service at 1-888-528-8518 prior to beginning work.

TEST FIRST

To ensure best results- it is suggested you first test and practice your technique in a less visible location such as in a closet.

REPAIR METHOD IF FLOOR IS SCRATCHED TO BARE WOOD

Touch up these deeper scratches with supplied DuroDesign touch-up oil stain. Let stain penetrate for 1 minute. If the color is not dark enough, repeat application of stain. Let dry 30 minutes. Apply the repair oil HR-1000. Let it penetrate the substrate for few minutes and wipe the excess. Repeat 2 or 3 times, if needed. After applying the final coat, let penetrate for few minutes and wipe with a dry cloth. When the final coat is close to dry, like traditional oil, buff the surface with a low abrasive disk (scotch brite) to make the gloss level match the rest of the floor.

REPAIR METHOD IF ONLY FINISH IS SCRATCHED

Apply a thin coat of HR-1000 to the scratch. Let the oil penetrate for 2 minutes and wipe off any excess with a dry cloth. Repeat if needed.

TO REFURBISH AN ENTIRE FLOOR

With a clean cloth, apply a thin coat of HR-1000 to one area at a time. Let the oil penetrate for 2 minutes and wipe off any excess with a dry cloth. Repeat if needed.

ENJOY

Allow your floor to dry 24 hours before subjecting it to normal traffic. Wait a week before replacing area rugs to allow the finish to fully cure.

These instructions were last updated in March 2009.

The most recent revision of this document is always available at <http://www.durodesign.com/>